FOX Memorandum



To: Fox Customers

From: Fox Racing Shox

Date: July 8, 2003

Re: Fox/Fabtech Rebuild Information

1. Clean shock.

2. De-pressurize shock completely. VERY IMPORTANT!

3. Unscrew bearing cap. You can use a 1"5/8 wrench or a crescent wrench.

4. Remove shaft/-bearing assembly, by rocking back and forth and pulling out at the same time.

5. Dump oil.

6. Remove internal floating piston (IFP). You may need to place shock in a container filled with rags and pressurize shock with shop air (80 psi max.). This should remove the IFP from the shock.

7. Place the shaft assembly in a vise with soft jaws. Remove piston nut. Remove valving and bearing assembly. Keep valving and piston in the order in which they were removed. 8. With a scribe remove all seals from bearing assembly and IFP. Remove the setscrew

from the bearing assembly.

9. Clean all parts.

10. Inspect all valve plates and damping piston, look for cracks or any signs of fatigue.

11. Check shaft to see that it is not bent or has any deep pits (rock dings), replace if needed.

12. Install new seals on all parts. Use a small amount of assembly lube on bearing assembly.

13. Install bearing and cap assemblies back onto shaft. Be careful not to tear any seals. 14. Install valving assembly and lock nut. Torque nut to 30 ft./lb. Install jam nut and torque to min. 40 ft/lb.

15. Clean body assembly, place it in a vise open end up.

16. Remove Schrader valve core.

17. Lube resealed IFP; install IFP so that the deep dish is visible.

18. Set the IFP to the correct depth (see chart). This step is very important! Reinstall the Schrader valve core once the IFP is set in the correct position.

19. Fill the shock body up to 2" from the open end with oil.

20. Insert shaft and valving assembly into shock. Stroke the shaft slowly several times. Gently tapping on the eyelet assembly will also help. You are trying to bleed any air that

may be trapped in the shock. Be sure to be very gentle doing this. You do not want to "bump" the IFP.

21. Top off the shock with oil to about 1/2" from the top.

22. Slowly insert the bearing assembly into the shock body. Oil will come out the bleed hole built into the bearing.

23. Torque the bearing assembly down to 55-60 ft/lb.

24. Install bearing assembly set screw.

25. Pressurize the shock with 200 psi. of nitrogen.

26. Remove the shock from the vise. Compress the shock to make sure it is working properly.

FABTECH FTS 2100/2200 IFP DEPTH

1) FTS 2100/2200 - Shock with 4.375" of travel (old style) = 8.700" IFP depth

2) FTS 2100/2200 - Shock with 4.775" of travel (new style) = 8.375" IFP depth

3) All dimensions are from the open end of the body to the highest point of the IFP.