

ORIFICES

Function

Orifices are used in hydraulic systems to restrict flow.

Sizing

To calculate the orifice diameter required to pass a desired flow at a specified pressure:

$$D = 0.23 \times \sqrt{(Q \div \Delta p)}$$

Where

D = orifice diameter in inches

Q = flow in US gallons per minute

Δp = differential pressure across orifice

And assuming: specific gravity = 1 and orifice coefficient = 0.63

To calculate the flow through an orifice of a known diameter at a specified pressure:

$$Q = (D \div 0.23)^2 \times \sqrt{\Delta p}$$

Where

Q = flow in US gallons per minute

D = orifice diameter in inches

Δp = differential pressure across orifice

And assuming: specific gravity = 1 and orifice coefficient = 0.63

To calculate the pressure drop (differential pressure) across an orifice of a known diameter at a specified flow:

$$\Delta p = [Q \div (D \div 0.23)^2]^2$$

Where

Δp = differential pressure across orifice

Q = flow in US gallons per minute

D = orifice diameter in inches

And assuming: specific gravity = 1 and orifice coefficient = 0.63

| Conversions | | | |
|-------------|---|-------|-------------|
| litre | ÷ | 3.785 | = US gallon |
| millimetre | ÷ | 25.4 | = inch |
| bar | × | 14.5 | = psi |

Hydraulic Secrets Revealed! [Click here to learn more...](#)